

































**PART LIST
TL8128 FOXTAIL VILLA**

A	B	C	D	E	F	
						
x1	x1	x1	x1	x1	x1	
G	H	I	J	K	L	M
						
x2	x1	x1	x1	x1	x2	x1
N	O	P	Q	R	S	T
						
x2	x4	x1	x1	x1	x1	x1
U	V	24	25	26	27	28
						
x1	x1	x1	x1	x4	x35	x12

ASSEMBLY INSTRUCTION


TL8128




ASSEMBLY INSTRUCTION

TL8128


6




7




8



9



10



Complete

