






















PART LIST

A	B	C	D	E
 x1 = 2	 x2	 x1	 x1	 x1 x1 x1 = 3
F	G	H	I	J
 x1	 x1	 x2	 x2	 x1
K	L	M	N	O
 x1	 x1	 x1	 x1	 x1
P	Q	R	S	T
 x1	 x1	 x1	 x2	 FX-12F x1

ASSEMBLY INTRUCTION

ITEM : TL8312



ADULT ASSEMBLE