































ASSEMBLY INSTRUCTION / INSTRUCTIUNI DE ASAMBLARE

TL8702



A	AA	B	C	E	F	K2
						
x6	x5	x1	x2	x7	x2	x1
R1		R2		UB-4	VB1	X101
						
x1		x1		x2	x1	x1 x1 x1 =4
201E	201F	201G		201H		201I
						
x1	x1	x2 x2 x2	x1 =7	x2 x3 x5 x5	x1 =16	x2 x2 =4
401B	401C	401D	401E	601D		
						
x1	x1	x1	x1	x1 x1 =2		
601E	601F	601G	601H	601I		
						
x2 x4 x6 x2 =14	x2 x1 x1 =4	x1	x1 x2 x1 =4	x1 x2 x1 =4		

ADULT ASSEMBLE / ASAMBLARE DE ADULTI