


ASSEMBLY INSTRUCTION / INSTRUCTIUNI DE ASAMBLARE

TL8817



PART LIST / LISTA PARTI COMPONENTE

A				x1
B		30		x2 x8
C		31		x4 x8
28		32		x4 x8
29				x8 FM-D x1

ADULT ASSEMBLE / ASAMBLARE DE ADULTI