


































## PART LIST

### TL8861 MULBERRY MANSION

A  x1	B  x1	C  x1	D  x1	E  x1	F  x1				
G  x1		H  x1	I  x1	J  x1	K  x1	L  x1			
M  x1	N  x1	O  x1	P  x1	Q  x1	R  x2	S  x1	T  x1	U  120 mm x2	V  110 mm x8
W  110 mm x2	X  x1	Y  x1	Z1  x2	Z2  x2	FF  x1	19  30 mm x2	20  38 mm x16	21  x16	22  24 mm x32
									23  30 mm x2

**Warning:** Adult assembly required. Serious or fatal crushing injuries can occur from doll house tipping over. To minimize the risk, we suggested to use the enclosed wall anchor kit. Please DON'T let your children to climb or pull on the dollhouse. This product contains small parts before assembling. Keep unassembled parts away from children.

# ASSEMBLY INSTRUCTION

TL8861

